
Unable to Read Screen

Written By: Frank Rupert Catapang




INTRODUCTION

If your Palette is turned on but you're unable to read your LCD screen, please check the following options.


© 2022

Step 1 — Option 1



- Check the screen cable connections within your Palette. Please refer to this article to check the connections.


Step 2 — Option 2



- Adjust the contrast potentiometer on the back of the LCD screen.
- To do this, take a Phillips head screwdriver to adjust the dial while the screen is on so that you can adjust until the screen is to your liking.

⚠ Please be careful to avoid any metal parts near the potentiometer with the screwdriver as this may short your screen.

Step 3 — Option 3



- The blank screen may be caused by static in the printing area around Palette+. In order to help avoid this issue, please print 8 plastic washers which you can install on each screw on the screen. You would place a washer between the screw and screen. Download the STL **here**.

If you have any questions, please contact us at support@mosaicmfg.com.